

# AnyWire Picking Terminal series/ Transparent Type

**A027PB-T02G-P/** light-emitting unit

**A027XB-T02G-C/** light-receiving unit

Eject check input

Eject indicator lamp (Orange)

AnyWire is the registered trademark of Anywire Corporation in Japan.

The AnyWire System Product Guide describes the individual products. Refer to the Guide as necessary.

## [Notes on Safety]

Precautions that must be observed in order to use this system safely are indicated as shown below. You must observe these precautions.



A WARNING indicates a potentially hazardous situation which, if not handled correctly, could result in death or serious injury.



A CAUTION indicates a potentially hazardous situation which, if not handled correctly, may result in personal injury or property damage.



- > System Safety  
This system is intended for general industrial applications. It does not have functions for supporting applications requiring higher levels of safety such as safety-related devices or accident prevention systems. The product must not be used for these purposes.
- > Always turn off the power before attempting installation or replacement.



- > System power supply  
Use a regulated, 24-VDC power supply. The use of a non-regulated power supply may cause problems with the system.
- > Separately route high-voltage and power cables  
Although the AnyWire Bitty series has high noise tolerance, always route transmission cables and I/O cables away from high-voltage and power cables.
- > Connectors and terminals
  - \* Pay careful attention to the length and installation of cable wiring to ensure that connectors and cables are neither overloaded nor disconnected.
  - \* Be careful to prevent any metal objects from entering the connectors or the terminal blocks.
  - \* Short-circuits caused by metal objects or mis-wiring are likely to damage the device.
- > Do not impose any external loads on the units. Doing so may cause a failure.
- > While the transmission line is energized, do not attempt to disconnect from the unit or re-connect slave units. Doing so may cause a malfunction.
- > Do not use this product as a power supply for the AnyWire Bitty series or to open/close the parallel signals of a single board controller (SBC) or other controllers. Using the same power supply for multiple units may lead to a system failure.
- > When using the AnyWire Bitty series, always conform to the specifications and conditions prescribed below.

## [Features]

- \* This product is compatible with the AnyWire Bitty series.
- \* Transparent picking unit
- \* The power is turned on when the light beam is interrupted.
- \* The transmission and supply of power are done using a regular two-wire cable.
- \* The detection range can be expanded by adding optional units.

## [Type]

### Bit Operation

A027PB-T02G-P	One point output	Eject indicator lamp (Green)
	With the address function	
A027XB-T02G-C	One point output	Eject indicator lamp (Green)
	One point input	Eject check input
	With the address function	

## [Warranty]

- > Warranty period  
The warranty on the delivered Product shall continue to be effective for one (1) year after the delivery thereof to a location as designated by the original owner.
- > Scope of warranty  
Should a defect occur in any part of the Product during the foregoing warranty period when it is used normally in accordance with the specifications described in this User's Manual, the Company shall replace or repair the defect free of charge, except when it arises as a result of:
  - [1] Misuse or abuse of the Product by the owner;
  - [2] Fault caused by other than the delivered Product;
  - [3] The unauthorized modification or repair of the Product by any person other than the Company's personnel;
  - [4] Any unusual force of nature, disasters and other causes beyond the Company's control.

The term "warranty," as used herein, refers to the warranty applicable to the delivered product alone. The Company shall not be liable for consequential or incidental damages resulting from any malfunction.
- > Repair at cost  
After the expiration of the warranty period, the owner shall be responsible for all costs and expenses incurred for the troubleshooting and repair of the Product. Even during the warranty term, the Company shall repair any defects arising from causes other than the scope of the warranty as specified above, at the owner's cost.


## [Connection]

The light-emitting and light-receiving units with the address function are fitted with a cabtyre cable for making the transmission line connection. Branch the cable from a transmission line by using a screw terminal block, link connector, or the like. For the trunk, use a cable with a size of at least 0.75 mm<sup>2</sup>.

### > Cable Specification


Purpose of connection	Outside diameter of sheath	Number of wires	Cable size	Cable length	Wiring color/signal name
For transmission line connection	φ6	4 wires	AWG #20*	Approx. 500 mm	DN : Black (transmission line**) DP : Red (transmission line**) 0 V : White (0V) 24 V : Green (DC24V)

\* Do not use an AWG #20 cable to extend the line  
\*\* Note polarity.



> To pressure-weld a link connector to the end of a unit cable

Use link connector 38104-F020-H00 FL, available from Sumitomo 3M Limited.



> Pin number, signal name, and cable color at pressure weld

1=DN (Black)  
2=DP (Red)  
3=0 V (White)  
4=24 V (Green)

This figure shows an A027XB-T02G-P light-receiving unit with the address function. This example is also applicable to the A027PB-T02G-P.



The use of a dedicated tool for pressure welding the link connector is recommended to attain a stable pressure weld.



SUZUDEN Co.,Ltd  
Type: L-Tool-N

### > Transmission line


Install the **AnyWire Bitty** series with 4-wire transmission lines (DP and DN) and power lines (24 V and 0 V). Prepare an **AnyWire**-dedicated power supply (general-purpose 24-VDC stabilized power supply rated at 100 W or greater).

It is recommended that the transmission master unit be installed close to a shelf to enable the efficient use of the power supplied by the power superimposed transmission.

You can use a commercial 4-wire cabtyre cable for the DP and DN lines. The transmission line can be **up to 50 m long (total length, including the unit cable)**. For the transmission line trunk, use a cable with a size of 0.75 mm<sup>2</sup> or greater.

If a dedicated flat cable (FK4-075-100) is used, a T-junction can be made using a link connector.

Since the link connectors can support a line size of up to 0.75 mm<sup>2</sup>, to use a trunk with a size of 1.25 mm<sup>2</sup>, use a screw terminal block to relay the cables directly, or if the trunk already has a link connector, use the link connector to relay the cables and then use a screw terminal block for relay.



Connect an AT0 terminator at the farthest end of the transmission line.




When installing a transmission line, route it as far away from the high-voltage and power cables as possible. Use one single transmission cable for each AnyWire Bitty series system. Do not attempt to combine two or more systems. Inappropriate installation and the combining of systems may lead to a malfunction.

> Select and purchase appropriate link connectors for the cables to be used.

### Link connector type example

	Wire sheath diameter	Type offered by Sumitomo 3M Limited
Link connector for 0.75-mm <sup>2</sup> cabtyre cables	Equivalent products to dedicated flat cables	38104-0018-000 FL
	φ 1.8 ... 2.1	38104-F018-F00 FL
	φ 2.1 ... 2.4	38104-E018-E00 FL



Terminator AT0

Black (DN)  
White (DP)




A terminator (AT0) is a composite element for stabilizing transmission waveforms. Connect an AT0 at the farthest end from the master with the transmission line. Note that an AT0 has polarities. (The LED lights during normal operation.) Incorrect connections may cause malfunctions or failures.

### > Number of units that can be connected

A total of **up to 50 units**, such as the A027PB-T02G-P and (add-on) A027XB-T02G-C without the address function, can be connected to a transmission master unit.

# [Connection Example]

The following shows an example of a connection from an AnyWire Bit distribution I/O Terminal (AB023-C1: CC-Link Gateway) to a light-emitting unit with the address function (A027PB-T02G-P) and a light-receiving unit with the address function (A027XB-T02G-C). The figure shows an example in which the connection is branched by link connectors.



## [Address Setting]

- \* Address numbers correspond to the input and output points of the controller.
- \* Set an address by using the address setting switches on the A027PB-T02G-P and A027XB-T02G-C units with the address function.
- The set number indicates the input and output address of the unit and occupies one point.
- This terminal checks and updates data on a bit-by-bit basis.
- \* You can set an address on a point-by-point basis.
- \* You cannot set 255.

### > Setting example


Bit address	Switch setting							
	1	2	4	8	16	32	64	128
0								
:	:	:	:	:	:	:	:	:
6		○	○					
:	:	:	:	:	:	:	:	:
254		○	○	○	○	○	○	○

- \* Speed setting is not supported.
- \* Set an address so as not to exceed the maximum number of transmission points, including the number of points of the local terminal.

**CAUTION** To change the switch setting, first turn off the power to the AnyWire system. Otherwise, a malfunction may occur.


\* Always set the same values for paired A027PB-T02G-P and A027XB-T02G-C units. If different values are set, no operation is performed.

"An eject indicator lamp" is provided for the A027PB-T02G-P and A027XB-T02G-C, and corresponds to Bit-Bus output.  
 "Eject check input" is output from A027XB-T02G-C, and corresponds to Bit-Bus input.



Light-emitting unit with the address function (front)

A027PB-T02G-P



Light-receiving unit with the address function (front)


A027XB-T02G-C

## [Monitor Indication]

- \* This unit has a monitor function.
- \* The LINK lamp indicates the system state, as explained in the table below.
- \* If the state is other than normal, turn the power off immediately, eliminate the cause, check for the cause, and then turn the power back on.
- \* The optical axis check indicator lamp of the light-receiving unit goes out when the optical axes of the light-emitting and light-receptive units are aligned and the unit enters the operation state.
- While the unit is in the operation state, the lamp changes to indicate operation, but if the light beam is interrupted, the lamp indicates input ON.

Indication LED	Indicative state	Monitor information
LINK (Red)	Flashing	Normal
	Goes out	Disconnection of power
	Lights up	Abnormal transmission
	Goes out	
Axis check operation indication (Red)	Goes out	Matching
	Lights up	Displaced
	Goes out	Input OFF
	Lights up	Input ON

Lights up Goes out



Light-receiving unit with the address function (front)

A027XB-T02G-C


# [Installation and Detection]

There are three detection positions on a terminal.  
 Install the unit so as to align the optical axes of the light-emitting and light-receiving units.  
 To check whether the optical axes are aligned, check the optical axis check indicator lamp on the light-receiving unit.  
 In the case of a (slave) unit without the address function, install and check it similarly.


The transmission indicator of the light-emitting unit with the address function flashes and the unit is placed in the operation state when the unit receives transmission clock.

The transmission indicator of the light-receiving unit flashes and the optical axis check indicator lamp lights up simultaneously, when the unit receives transmission clock.  
 Then, when the unit receives an optical signal from the light-emitting side, the initial setting function operates first and the indicator lamp lights out after about one second, and then the unit is placed in the operation state.  
 After placed in the operation state, the indicator lamp lights up when light is interrupted (ON is detected).


When the optical axis check indicator lamp does not light out  
 \* re-adjust the optical axes  
 \* check whether the addresses of the light-emitting and the light-receiving units with the address function match.



Light-emitting unit (front)  
A027PB-T02G-P



Light-receiving unit (front)  
A027XB-T02G-C




\* Do not install the unit in the environment where the unit is exposed to sunlight and other disturbance light.  
 If light is not interrupted, turn the sensitivity adjustment knob right to adjust sensitivity. However, it shortens the detectable distance.

⇒ Slide this cover to operate the sensitivity adjustment knob.

At detection, make sure that the light is interrupted at any of three positions (hatched areas) for at least 0.2 seconds.  
 If a (slave) unit without the address function is added, the light beam must be interrupted at any of six detection positions.

**CAUTION** Do not forcibly pull a cable.  
 Do not fix a unit while its cable is under tension.  
 Otherwise, a failure may occur.




## [Addition of Units]

A single A027-T-P or A027-T-C unit, without the address setting function, can be independently added to the A027PB-T02G-P and A027XB-T02G-C light-emitting and light-receiving units with the address function. Doing so increases the detectable range vertically.

### Even if a unit is added, only one point is occupied.

The eject indicator lamp of the A027-T-P and A027-T-C units without the address setting function does not light up, but the units do have this detection function.

#### > Connection




\* If no unit is added, make sure that no foreign objects can get into the connector.

**CAUTION** Before adding a unit, turn off the power to the AnyWire system. Otherwise, a malfunction may occur.


# [Outer Dimensions]

Unit: mm

Light-emitting unit with the address function (A027PB-T02G-P)




Mass: 60 g



**[Outer Dimensions]**

Unit: mm

Light-receiving unit with the address setting function (A027XB-T02G-C)






**[Outer Dimensions]**

Unit: mm

Light-emitting unit without the address function (A027-T-P)




Mass: 30 g

[Outer Dimensions]

Unit: mm

Light-receiving unit without the address setting function (A027-T-C)



[Address]

---



Headquarters:

8-1, Shimoinden, Inouchi, Nagaokakyo-shi, Kyoto 617-0813 JAPAN

TEL:075-956-1611 / FAX:075-956-1613

East Japan Office:

47, Kandakonya-cho, Chiyoda-ku, Tokyo 101-0035 JAPAN

TEL:03-5209-5711 / FAX:03-5209-5713

Chubu Office:

2-26-15-507, Noritake, Nakamura-ku, Nagoya-shi, Aichi 453-0014 JAPAN

TEL: 052-452-8711 FAX: 052-452-8713

Kyoto Factory:

19-2, Umatate, Kamiueno-cho, Muko-shi, Kyoto 617-0006 JAPAN

TEL:075-922-1911 / FAX:075-922-1913

Printed in Japan2006 UMA-0A